



Note that this pump was ordered with the flange option selected. This is denoted by an “F” in second to last digit of your pump model number. Or a flange kit was ordered for your existing pump.

You will find four (4) loose flange halves in the pump box. When two (2) halves are put together, they will form a loose flange for easy bolt up to your piping system. When placed around the manifold and angled away from one another, they can be fit together by inserting the raised rings around two (2) of the slots into the large two slots. They can then be brought parallel to one another. The recess fits behind the raised collar of the manifold creating a raised face Van Stone style flange.

You will also find shims, bolts, nuts, and washers. These can be used if the installation does not allow the flange to extend below the pump foot. Inserting the bolts from the bottom of the shims will allow the pump to sit flat on the shims if the pump is not anchored. These shims will raise the pump by 1-1/2”.

